

Mounting Instructions

2000-01-10 38-081400a

General

Identify all parts before installation. Installation shall be done in a proper and competent manner. Always follow the instructions. Give the customer all directives and instructions so that these can be kept in the vehicle for future service and maintenance.

Mounting

- Coat the conic rubber bushings with tyre mounting paste or another water soluble anti-frictional paste. Do not use mineral oil.
- Oil the entire bolt and the surface between the washers and the conic bushings.
- Fit the drawbar in the trailer drawbar bracket and mount the mounting parts according to the figure.
- Tightening torque M27 650 Nm

